

4602/4602SW SIP IP Telephone

Quick Reference



Making and Receiving Calls:

- To make a call, pick up the handset and dial your party.
- or -
Pick up the handset and press **Redial** to call the last person you dialed.
- To receive a call, pick up the handset and, if necessary, press the **Line** button indicated on the display.